

| KRONES CONTIFORM C3 SAN |                                   | 6000HR PREVENTIVE MAINTENANCE |               |
|-------------------------|-----------------------------------|-------------------------------|---------------|
| Asset Activity:         | Krones Contiform C3 SAN 6000hr PM | Work Order #:                 | SEED-20260507 |
| Machine ID:             | CONTIFORM-C3-L3                   | Actual Start Date:            | _____         |
| Interval:               | 6000 Operating Hours              | Actual End Date:              | _____         |
| Team Member(s):         | System Generated                  | Machine Hours:                | _____         |
| Generated:              | 07 May 2026 18:55 UTC             | Comments:                     | _____         |

| STOPPED TASKS |         |         |                                                                                                                                                                                                         |         |                               |
|---------------|---------|---------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------|-------------------------------|
| TASK #        | AREA    | ACTION  | DESCRIPTION                                                                                                                                                                                             | INITIAL | DONE <input type="checkbox"/> |
| 10            | SAFETY  | CONFIRM | ALL 6000HR TASKS REQUIRE KRONES-AUTHORISED SERVICE ENGINEER ATTENDANCE &” ARRANGE KRONES SERVICE VISIT IN ADVANCE &” DO NOT COMMENCE 6000HR WORK WITHOUT KRONES ENGINEER ON SITE                        |         | <input type="checkbox"/>      |
| 20            | INSPECT | CHECK   | INSPECT ALL GUARD DOORS, HINGES, GAS STRUTS, INTERLOCKS AND SAFETY SWITCHES FOR WEAR, DAMAGE AND CORRECT FUNCTION &” REPLACE ANY COMPONENT THAT DOES NOT MEET SAFETY STANDARD                           |         | <input type="checkbox"/>      |
| 30            | INSPECT | CHECK   | INSPECT AND SERVICE ELECTRICAL CABINET AIR CONDITIONING UNIT &” CLEAN FILTERS, CHECK REFRIGERANT LEVEL AND CONDENSER COILS &” ARRANGE SPECIALIST SERVICE IF REFRIGERANT IS LOW                          |         | <input type="checkbox"/>      |
| 40            | REPLACE | REPLACE | REPLACE ALL HIGH-PRESSURE BLOW AIR FILTER ELEMENTS &” MAIN PARTICULATE FILTER AND COALESCENT FILTER &” USE KRONES SPECIFIED PARTS ONLY &” RECORD PART NUMBERS IN MAINTENANCE LOG [PART: KRONES-HPF-001] |         | <input type="checkbox"/>      |
| 50            | INSPECT | CHECK   | COMPLETE KRONES ANNUAL MACHINE INSPECTION &” ALL ITEMS PER KRONES STANDARD INSPECTION CHECKLIST &” KRONES ENGINEER TO DOCUMENT ALL FINDINGS AND CORRECTIVE ACTIONS REQUIRED                             |         | <input type="checkbox"/>      |
| 60            | INSPECT | CHECK   | CHECK ALL PRESSURE VESSELS AND SAFETY RELIEF VALVES &” VERIFY CERTIFICATION DATES ARE CURRENT &” IF ANY CERTIFICATE HAS EXPIRED ARRANGE RECERTIFICATION BEFORE RETURNING MACHINE TO SERVICE             |         | <input type="checkbox"/>      |
| 70            | INSPECT | CHECK   | INSPECT ALL HYDRAULIC AND PNEUMATIC HOSE LINES THROUGHOUT MACHINE &” CHECK FOR HARDENING, SURFACE CRACKING, CHAFING OR DAMAGE &” REPLACE ALL AGED HOSES AS PREVENTIVE MEASURE                           |         | <input type="checkbox"/>      |
| 80            | GENERAL | CONFIRM | OBTAIN KRONES ENGINEER WRITTEN SIGN-OFF ON COMPLETED ANNUAL INSPECTION &” SUBMIT COMPLETED REPORT TO MAINTENANCE MANAGER &” FILE IN EQUIPMENT HISTORY &” REMOVE ALL LOTO AND REINSTATE                  |         | <input type="checkbox"/>      |

|                  |       |                      |       |       |       |
|------------------|-------|----------------------|-------|-------|-------|
| Technician Name: | _____ | Supervisor Approval: | _____ | Date: | _____ |
|------------------|-------|----------------------|-------|-------|-------|

| PARTS / CONSUMABLES REQUIRED |                                       |     |         |            |               |                  |
|------------------------------|---------------------------------------|-----|---------|------------|---------------|------------------|
| PART NUMBER                  | DESCRIPTION                           | UOM | REQ QTY | ISSUED QTY | PICK LOCATION | MECHANIC INITIAL |
| KRONES-HPF-001               | High-Pressure Blow Air Filter Element | EA  |         |            |               |                  |

|                                                                                                                                                                                                                                                                                                                       |
|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| **** END OF REPORT ****                                                                                                                                                                                                                                                                                               |
| GENERAL — PRIOR TO RETURNING TO SERVICE FOLLOW ALL GMP PROCEDURES                                                                                                                                                                                                                                                     |
| <div><div><input type="checkbox"/> Remove all LOTO (Lockout/Tagout) devices before returning to service</div><div><input type="checkbox"/> Re-check all E-STOP (Emergency Stop) and control switches</div><div><input type="checkbox"/> This document must be signed and retained as a maintenance record</div></div> |
| Document hash: (see system)   Generated: 2026-05-07 18:55 UTC   System: PM Automation v1.0                                                                                                                                                                                                                            |