

KRONES CONTIFORM C3 SAN		6000HR PREVENTIVE MAINTENANCE	
Asset Activity:	Krones Contiform C3 SAN 6000hr PM	Work Order #:	SEED-20260508
Machine ID:	CONTIFORM-C3-L3	Actual Start Date:	_____
Interval:	6000 Operating Hours	Actual End Date:	_____
Team Member(s):	System Generated	Machine Hours:	_____
Generated:	08 May 2026 15:42 UTC	Comments:	_____

STOPPED TASKS					
TASK #	AREA	ACTION	DESCRIPTION	INITIAL	DONE ☐
10	SAFETY	CONFIRM	ALL 6000HR TASKS REQUIRE KRONES-AUTHORISED SERVICE ENGINEER ATTENDANCE â€” ARRANGE KRONES SERVICE VISIT IN ADVANCE â€” DO NOT COMMENCE 6000HR WORK WITHOUT KRONES ENGINEER ON SITE		☐
20	INSPECT	CHECK	INSPECT ALL GUARD DOORS, HINGES, GAS STRUTS, INTERLOCKS AND SAFETY SWITCHES FOR WEAR, DAMAGE AND CORRECT FUNCTION â€” REPLACE ANY COMPONENT THAT DOES NOT MEET SAFETY STANDARD		☐
30	INSPECT	CHECK	INSPECT AND SERVICE ELECTRICAL CABINET AIR CONDITIONING UNIT â€” CLEAN FILTERS, CHECK REFRIGERANT LEVEL AND CONDENSER COILS â€” ARRANGE SPECIALIST SERVICE IF REFRIGERANT IS LOW		☐
40	REPLACE	REPLACE	REPLACE ALL HIGH-PRESSURE BLOW AIR FILTER ELEMENTS â€” MAIN PARTICULATE FILTER AND COALESCENT FILTER â€” USE KRONES SPECIFIED PARTS ONLY â€” RECORD PART NUMBERS IN MAINTENANCE LOG [PART: KRONES-HPF-001]		☐
50	INSPECT	CHECK	COMPLETE KRONES ANNUAL MACHINE INSPECTION â€” ALL ITEMS PER KRONES STANDARD INSPECTION CHECKLIST â€” KRONES ENGINEER TO DOCUMENT ALL FINDINGS AND CORRECTIVE ACTIONS REQUIRED		☐
60	INSPECT	CHECK	CHECK ALL PRESSURE VESSELS AND SAFETY RELIEF VALVES â€” VERIFY CERTIFICATION DATES ARE CURRENT â€” IF ANY CERTIFICATE HAS EXPIRED ARRANGE RECERTIFICATION BEFORE RETURNING MACHINE TO SERVICE		☐
70	INSPECT	CHECK	INSPECT ALL HYDRAULIC AND PNEUMATIC HOSE LINES THROUGHOUT MACHINE â€” CHECK FOR HARDENING, SURFACE CRACKING, CHAFING OR DAMAGE â€” REPLACE ALL AGED HOSES AS PREVENTIVE MEASURE		☐
80	GENERAL	CONFIRM	OBTAIN KRONES ENGINEER WRITTEN SIGN-OFF ON COMPLETED ANNUAL INSPECTION â€” SUBMIT COMPLETED REPORT TO MAINTENANCE MANAGER â€” FILE IN EQUIPMENT HISTORY â€” REMOVE ALL LOTO AND REINSTATE		☐

Technician Name:	_____	Supervisor Approval:	_____	Date:	_____
------------------	-------	----------------------	-------	-------	-------

PARTS / CONSUMABLES REQUIRED						
PART NUMBER	DESCRIPTION	UOM	REQ QTY	ISSUED QTY	PICK LOCATION	MECHANIC INITIAL
KRONES-HPF-001	High-Pressure Blow Air Filter Element	EA				

**** END OF REPORT ****
GENERAL — PRIOR TO RETURNING TO SERVICE FOLLOW ALL GMP PROCEDURES
☐ Remove all LOTO (Lockout/Tagout) devices before returning to service ☐ Re-check all E-STOP (Emergency Stop) and control switches ☐ This document must be signed and retained as a maintenance record
Doc-ID: 2d8e9000af2b32b9 WO: SEED-20260508 Generated: 2026-05-08 15:42 UTC PM Automation System v1.0